

WF-B series Spice Grinder

Thanks for choosing LINKRICH products:

We mainly produce food processing equipment, baking equipment, professional kitchen equipment, steel kitchen ware, commercial refrigeration equipment and ice cream machine, more than 6 series, 127 kinds of products for you to choose. They are environment-friendly with excellent designs. High technique to save power, complete functions, easy to operate, LINKRICH products are more competitive than those of the same line in the international market.

ATTENTION

- New user or repairing this product must be performed by the experts or qualified person or those who have gotten the license of installation, or those who are authorized by the manufacturer.
- When installation or maintenance, please obey the following instructions carefully to ensure the safety use of this appliance.
- Please keep this instruction Manual for future reference, or hand it to next user.
- Put off the package to make sure none of the parts is missing or damaged. If there is any doubt about the product, please do not use it, and consult it to the experts.
- Keep the packing material out of reach of the children to avoid accident(Especially the plastic bag, screw etc)
- This appliance could be only operated by the person who is familiar with the unit.
- When not using the appliance or the operator is absent, please turn off the unit to avoid any accidental injury or damage.
- When it needs to be repaired, please ask for expert, and use the original fitted spare part. It will be dangerous if not following the above requirements.
- This appliance is just for commercial using, not for any other use, otherwise, it may be dangerous.
- Do not rinse the equipment with water directly.
- Clean the surface of stainless steel periodically with appropriate method to prevent any damage brought by oxidization or any other chemical interference.

Directions for use

Open the cover, material is loaded

Will cover shut

Put through power supply, open the timer switch, switch on operation (rolling noise) will happen

Turn the power off (when hear rolling is even, had been crushed into a powder, can be turned off)

Open the cover, poured out powder

Matters needing attention

Just boot, if meet crushing stuck blade, make the motor does not turn (will hum bass sound), immediately shut off the power, to prevent motor burn out, then the card removed, to boot.

General Chinese medicine pieces just half a minute, hard powder can be a minute. Grinding time should not be too long, prevent the fine powder hot glue tank.

The machine can't long time continuous operation, the boot time shall not exceed 5 minutes every time, the processing quantity, middle must rest (pause) to prevent damage to the motor bearing overheating

Use for a long time, carbon brush and blade wear serious when you want to change the new (spare parts)

To prevent the machine fell to the ground and broke

Material must be dry, unfavorable moisture and grease

The cover is opened, please do not start switch

Spare parts: (1)two blades (2) the brush brush
(3)the carbon brush 1pair (4)two fuses

Common small failure causes and elimination methods

After electrify light is not bright

Reason: please check the plug socket is bad contact, whether the indicator light to show only electricity

Method: change the lug plate or socket

After electrify indicator, turn on the switch, the machine is not running

Causes: voltage instability or super load using overload protector pop-up, protect the motor

Method: please immediately cut off the power supply, lighten the load, overload protector, red button, can be normal use

Buzzing sound, after electrify motor rotate too slow or not

Reason: please check whether the crushing material moisture, excess stuck blades

Please check whether the carbon brush is badly worn

Excluded methods: immediately cut off the power and remove the jammed material, change of carbon brush

If after electrify motor does not turn

Reason: please check whether the overload protector of pop, please check whether the material is too much like a pop-up or card slot, and then reset

If try still not back to normal after the operation, please contact the dealer

Technical parameters

Model	Voltage (V)	Power (Kw)	motor speed (r/min)	Net Weight (Kg)	Grinding fineness (section)
WF-2B	220	0.65	28000	3.2	500-300
WF-3B	220	0.85	28000	3.5	500-300
WF-4B	220	1.2	28000	4.2	500-300
WF-6B	220	1.5	28000	6	500-300
WF-8B	220	1.8	25000	7	500-300
WF-10B	220	2	25000	9	500-300
WF-16B	220	2.4	25000	10	500-300
WF-20B	220	3	25000	10.5	500-300
WF-25B	220	3.5	25000	11	500-300
WF-30B	220	3.8	25000	11.5	500-300

ONE YEAR PARTS WARRANTY

LINKRICH warrants to the original purchaser of every new LINKRICH product, under normal and proper use and maintenance service as specified by LINKRICH and upon proper installation and start-up in accordance with the instruction packet supplied with each LINKRICH unit. LINKRICH's obligation under this warranty is limited to a period of one (1) year from the date of original installation.

WARRANTY CLAIMS

All claims for parts must be made directly through LINKRICH. All claims should include:

Personal Details:

Your name

Your company

Address

Email

Phone

Products Details:

Model number

Serial number of the product

Date of purchase

Proof of purchase

Pertinent information supporting the existence of the alleged defect.(Such as picture etc.)

Please send the above information to Service@chinalinkrich.com or Fax to +86 20 87607453

Our warranty departments will according to the actual situation and reply you within 24hours.

What is not conected by this Warranty

Linkrich's sole obligation under this warranty is limited to replacement of parts, Subject to the additional limitations below.

This warranty neither assumes nor authorizes any person to assume obligations other than those expressly covered by this warranty. This warranty is limited to replacement of parts, and the shipment charge is not included.

No consequential damages. Linkrich is not responsible for Economic loss; or special, indirect, or consequential damages, including without limitation, losses or damages arising from food or product spoilage claims whether or not account of refrigeration failure.

Warranty is not transferable. This warranty is not assignable and applies only in favor the original purchaser/user to whom delivered. Any such assignment or transfer shall avoid the warranties herein made and shall avoid all warranties, express or implied, including any warranty of merchantability or fitness for a particular purpose.

Improper usage . Linkrich assumes no liability for parts or labor coverage for component failure or other damages resulting from improper usage or installation or failure to clean and/or maintain product as set forth in the warranty packet provided with the unit.

Residential applications: linkrich assumes no liability for parts or labor coverage for component failure or other damages resulting from installation in non-commercial or residential applications.

Alteration, neglect, abuse, issue, accident, damage during transit or installation, fire, flood, acts of god. Linkrich is not responsible for the repair or replacement of any parts that linkrich determines have been subjected after the date of manufacture to alteration, neglect, abuse, accident, damage during transit or installation, fire, flood, or act of god.

Improper electrical connections. Linkrich is not responsible for the repair or replacement of failed or damaged components resulting from electrical power failure, the use of extension cords, low voltage, or voltage drops to the unit.

No implied warranty of merchantability or fitness for a particular purpose: there are no other warranties, expressed, implied or statutory, except the one (1) year parts warranty as described above. These warranties are exclusive and in lieu of all other warranties, including implied warranty and merchantability or fitness for a particular purpose. These are no warranty which extend beyond the description on the face hereof.